REMOTE

RM-DOAS-7A-1

## REFERENCES

- 1. SEE DRAWING 7A-I-0-7-04 DRUG PRODUCT BMS ARCHITECTURE
- 2. SEE DRAWING 7A-M-0-5-28 DRUG PRODUCT AFD DOAS-7A-1

## NOTES

- 1. POWER SUPPLY (220 VAC @ 60HZ) TO REMOTES PANEL IS SCOPE OF ELECTRIC DISCIPLINE.
- FOR 220 VAC SHALL USE RED MONOPOLAR CABLE AND BLACK MONOPOLAR CABLE RED, SIZE 2.5 MM2. FOR 24 VDC SHALL USE BLUE MONOPOLAR CABLE FOR 24 VDC(+) AND WHITE MONOPOLAR CABLE FOR VDC (-), SIZE 2.5 MM2.
- 3. GENERAL GROUNDING (GND) MUST BE CONNECTED TO GROUNDING BUS IN THE CONTROL PANEL INTERIOR AT BOTTOM OF THE CABINET.
- 4. ELECTRICAL MUST GROUNDING THE FOLLOWING: DOOR, PLATE, AND PANEL
- 5. USE A SINGLE CONDUCTOR GREEN OR GREEN-YELLOW INSULATION TO CONNECT THE EQUIPMENTS WHITH THE BAR BUS.
- 6. EACH CABLE WITHIN THE CONTROL PANEL SHALL BE PERMANENTLY TAGGED AND IDENTIFIED AT BOTH ENDS.
- 7. FOR ALL TERMINAL BLOCKS NUMBERS AND POINT IDENTIFICATIONS SHALL BE PERMANENTLY MARKED BY MARKING STRIPS ON TERMINAL STRIPS.
- 8. IDENTIFICATION SHALL BE TERMINAL BLOCK NUMBERS AND POINT NUMBERS SHOWN ON THE WIRING DIAGRAMS.
- 9. IS THE CONTRACTOR RESPONSIBILITY TO CONSIDER THE MISCELLANEOUS NECESSARY TO GUARANTEE ALL THE CONNECTIONS AND CORRECT INSTALLATION.

## REVISION O NOTES

- 1. UPDATE AND CORRECTIONS IN SHEETS REQUESTED
- 2. UPDATE IN ITEM DRAWINGS REFERENCE.

0	03SET2021	ISSUE FOR CONSTRUCTION	AAS	MAF	RSP	
Α	25MAY2021	90% DD ISSUE	AAS	MAF	RSP	
	DATE	DESCRIPTION	DRAWING BY	ENGINEER	REVIEWED	





7A-I-0-3-25























